

machine connection: drain connection hose, DN 22 hose fitted as odour trap in interior of machine drain (max. 300 mm above finished floor level), DN 50 2.0 Machine connection: fresh water supply, G 3/4"

2.5 Cold water 10°C, 20 DN, G 3/4 a Flow rate: total 4.3 l/min (at 15 °C inlet temperature and a flow pressure of 200 kPa / 2 bar)

electrical conductibility < 1000 μS/cm Minimum flow pressure: 100 kPa / 1.0 bar in front of solenoid valve Maximum pressure: 500 kPa / 5.0 bar in front of pressure reducer stopcock and fine screen ≤ 25 µm

3.0 Machine connection: electrical connection cable 5G 4.0mm²

electricity supply to the machine: 3N PE 400V ~ 50Hz nominal current / - capacity: 19.6 A / 12.4 kW Fuse protection: 25 A ♦ Voltage equalising cable

6.0 Heat load of warewash area

for 6 programme cycles/h total 0.6 kW, perceptible 0.4 kW, latent 0.2 kW

9.0 Compressed air connection

9.1 Compressed air: Specially cleaned and de-oiled breathing air to EN 12021 - Pressure between 2 and max. 5 bar Hose connection line approx. 4 m

all cables, pipes etc leaving machine 1,4 m

the position of the connection piping can also be mirror-inverted!

Machine Equipment

(A) Entry height

Rinse agent pipe and suction lance with empty indicator (blue connector)

Detergent pipe and suction lance with empty indicator

GiO MODULE (plinth, 120 mm)

Back wall cladding

ase observe the installation indications of the additional ocument MP_T-INFO-GIO_EN.pdf









